



FITS SERIES 2 & 3 ATTACHMENTS



STALL TYPE INSTALLATION

5/64" / 1.98 mm JIFFY KEY



FOR 12 POINT CONFIGURATION ADD X AFTER SOCKET OR SOCKET ACCESSORY ASSEMBLY NUMBER.

LENGTH OF SOCKET

JIFFY KEY HEX	SOCKET HEX	DESCRIPTION	1/4"	1/2"	1"	1 1/2"	2"	2 1/2"	3"
5/64" 1.98 mm	7/32" 5.56 mm	SOCKET ACCESSORY ASSEMBLY	18194	18195	18196	18197	18198	18199	18200
		SOCKET	12679	12680	12681	12682	12683	12684	12685
		JIFFY KEY STALL	18134	18135	18136	18137	18138	18139	18140
	1/4" 6.35 mm	SOCKET ACCESSORY ASSEMBLY	18201	18202	18203	18204	18205	18206	18207
		SOCKET	12686	12687	14446	12688	12689	12690	12691
		JIFFY KEY STALL	18134	18135	18136	18137	18138	18139	18140
	9/32" 7.14 mm	SOCKET ACCESSORY ASSEMBLY	18208	18209	18210	18211	18212	18213	18214
		SOCKET	12692	12693	12694	12695	12696	12697	12698
		JIFFY KEY STALL	18134	18135	18136	18137	18138	18139	18140
	5/16" 7.93 mm	SOCKET ACCESSORY ASSEMBLY	18215	18216	18217	18218	18219	18220	18221
		SOCKET	12699	12700	14445	12701	12702	12703	12704
		JIFFY KEY STALL	18134	18135	18136	18137	18138	18139	18140
	1 1/32" 8.73 mm	SOCKET ACCESSORY ASSEMBLY	18222	18223	18224	18225	18226	18227	18228
		SOCKET	12705	12706	12707	12708	12709	12710	12711
		JIFFY KEY STALL	18134	18135	18136	18137	18138	18139	18140
	3/8" 9.52 mm	SOCKET ACCESSORY ASSEMBLY	18229	18230	18231	18232	18233	18234	18235
		SOCKET	12767	12768	12769	12770	12771	12772	12773
		JIFFY KEY STALL	18134	18135	18136	18137	18138	18139	18140