



# FITS SERIES 2 & 3 ATTACHMENTS

## STALL TYPE INSTALLATION 1/8" / 3.17 mm JIFFY KEY



FOR 12 POINT CONFIGURATION ADD X AFTER SOCKET OR SOCKET ACCESSORY ASSEMBLY NUMBER.

### LENGTH OF SOCKET

| WRENCH TIP HEX  | SOCKET HEX        | DESCRIPTION               | 1/4"  | 1/2"  | 1"    | 1 1/2" | 2"    | 2 1/2" | 3"    |
|-----------------|-------------------|---------------------------|-------|-------|-------|--------|-------|--------|-------|
| 1/8"<br>3.17 mm | 3/8"<br>9.52 mm   | SOCKET ACCESSORY ASSEMBLY | 18264 | 18265 | 18266 | 18267  | 18268 | 18269  | 18270 |
|                 |                   | SOCKET                    | 12767 | 12768 | 12769 | 12770  | 12771 | 12772  | 12773 |
|                 |                   | JIFFY KEY STALL           | 18148 | 18149 | 18150 | 18151  | 18152 | 18153  | 18154 |
|                 | 7/16"<br>11.11 mm | SOCKET ACCESSORY ASSEMBLY | 18271 | 18272 | 18273 | 18274  | 18275 | 18276  | 18277 |
|                 |                   | SOCKET                    | 12872 | 12873 | 12874 | 12875  | 12876 | 12877  | 12878 |
|                 |                   | JIFFY KEY STALL           | 18148 | 18149 | 18150 | 18151  | 18152 | 18153  | 18154 |
|                 | 1/2"<br>12.7 mm   | SOCKET ACCESSORY ASSEMBLY | 18471 | 18472 | 18473 | 18474  | 18475 | 18476  | 18477 |
|                 |                   | SOCKET                    | 18485 | 18486 | 18487 | 18488  | 18489 | 18490  | 18491 |
|                 |                   | JIFFY KEY STALL           | 18148 | 18149 | 18150 | 18151  | 18152 | 18153  | 18154 |
|                 | 9/16"<br>14.29 mm | SOCKET ACCESSORY ASSEMBLY | 18478 | 18479 | 18480 | 18481  | 18482 | 18483  | 18484 |
|                 |                   | SOCKET                    | 18492 | 18493 | 18494 | 18495  | 18496 | 18497  | 18498 |
|                 |                   | JIFFY KEY STALL           | 18148 | 18149 | 18150 | 18151  | 18152 | 18153  | 18154 |