


FITS SERIES 4 ATTACHMENTS

STALL TYPE INSTALLATION

5/32" / 3.97 mm JIFFY KEY




SOCKET HEX MUST
MATCH COLLAR HEX



JIFFY KEY HEX
MUST
MATCH PIN RECESS HEX

SOCKET ACCESSORY
ASSEMBLY



FOR 12 POINT CONFIGURATION ADD X AFTER SOCKET OR
SOCKET ACCESSORY ASSEMBLY NUMBER.

5/32"
3.97 mm

		DESCRIPTION	1/2"	1"	1 1/2"	2"	2 1/2"	3"
5/32" 3.97 mm	7/16"	SOCKET ACCESSORY ASSEMBLY	19165	19166	19167	19168	19169	19170
		SOCKET	19049	19050	19051	19052	19053	19054
		JIFFY KEY STALL	19007	19008	19009	19010	19011	19012
5/32" 3.97 mm	1/2"	SOCKET ACCESSORY ASSEMBLY	19171	19172	19173	19174	19175	19176
		SOCKET	19055	19056	19057	19058	19059	19060
		JIFFY KEY STALL	19007	19008	19009	19010	19011	19012
5/32" 3.97 mm	9/16"	SOCKET ACCESSORY ASSEMBLY	19177	19178	19179	19180	19181	19182
		SOCKET	19061	19062	19063	19064	19065	19066
		JIFFY KEY STALL	19007	19008	19009	19010	19011	19012
5/32" 3.97 mm	5/8"	SOCKET ACCESSORY ASSEMBLY	19183	19184	19185	19186	19187	19188
		SOCKET	19067	19068	19069	19070	19071	19072
		JIFFY KEY STALL	19007	19008	19009	19010	19011	19012
5/32" 3.97 mm	11/16"	SOCKET ACCESSORY ASSEMBLY	19189	19190	19191	19192	19193	19194
		SOCKET	19073	19074	19075	19076	19077	19078
		JIFFY KEY STALL	19007	19008	19009	19010	19011	19012
5/32" 3.97 mm	3/4"	SOCKET ACCESSORY ASSEMBLY	19195	19196	19197	19198	19199	19200
		SOCKET	19079	19080	19081	19082	19083	19084
		JIFFY KEY STALL	19007	19008	19009	19010	19011	19012