



FITS SERIES 4 ATTACHMENTS



STALL TYPE INSTALLATION 7/32 / 5.56 mm JIFFY KEY



FOR 12 POINT CONFIGURATION ADD X AFTER SOCKET OR SOCKET ACCESSORY ASSEMBLY NUMBER.

LENGTH OF SOCKET

JIFFY KEY HEX	SOCKET HEX	DESCRIPTION	1/2"	1"	1 1/2"	2"	2 1/2"	3"
7/32" 5.56 mm	9/16" 14.29 mm	SOCKET ACCESSORY ASSEMBLY	19237	19238	19239	19240	19241	19242
		SOCKET	19061	19062	19063	19064	19065	19066
		JIFFY KEY STALL	19019	19020	19021	19022	19023	19024
	5/8" 15.87 mm	SOCKET ACCESSORY ASSEMBLY	19243	19244	19245	19246	19247	19248
		SOCKET	19067	19068	19069	19070	19071	19072
		JIFFY KEY STALL	19019	19020	19021	19022	19023	19024
	1 1/16" 17.46 mm	SOCKET ACCESSORY ASSEMBLY	19249	19250	19251	19252	19253	19254
		SOCKET	19073	19074	19075	19076	19077	19078
		JIFFY KEY STALL	19019	19020	19021	19022	19023	19024
	3/4" 19.05 mm	SOCKET ACCESSORY ASSEMBLY	19255	19256	19257	19258	19259	19260
		SOCKET	19079	19080	19081	19082	19083	19084
		JIFFY KEY STALL	19019	19020	19021	19022	19023	19024
	13/16" 20.64 mm	SOCKET ACCESSORY ASSEMBLY	19261	19262	19263	19264	19265	19266
		SOCKET	19085	19086	19087	19088	19089	19090
		JIFFY KEY STALL	19019	19020	19021	19022	19023	19024
	7/8" 22.22 mm	SOCKET ACCESSORY ASSEMBLY	19267	19268	19269	19270	19271	19272
		SOCKET	19091	19092	19093	19094	19095	19096
		JIFFY KEY STALL	19019	19020	19021	19022	19023	19024