



# FITS SERIES 4 ATTACHMENTS



## STALL TYPE INSTALLATION 1/4" / 6.35 mm JIFFY KEY



FOR 12 POINT CONFIGURATION ADD X AFTER SOCKET OR SOCKET ACCESSORY ASSEMBLY NUMBER.

### LENGTH OF SOCKET

JIFFY KEY HEX	SOCKET HEX	DESCRIPTION	1/2"	1"	1 1/2"	2"	2 1/2"	3"
<b>1/4"</b> 6.35 mm	<b>5/8"</b> 15.87 mm	SOCKET ACCESSORY ASSEMBLY	19273	19274	19275	19276	19277	19278
		SOCKET	19067	19068	19069	19070	19071	19072
		JIFFY KEY STALL	19025	19026	19027	19028	19029	19030
	<b>11/16"</b> 17.46 mm	SOCKET ACCESSORY ASSEMBLY	19279	19280	19281	19282	19283	19284
		SOCKET	19073	19074	19075	19076	19077	19078
		JIFFY KEY STALL	19025	19026	19027	19028	19029	19030
	<b>3/4"</b> 19.05 mm	SOCKET ACCESSORY ASSEMBLY	19285	19286	19287	19288	19289	19290
		SOCKET	19079	19080	19081	19082	19083	19084
		JIFFY KEY STALL	19025	19026	19027	19028	19029	19030
	<b>13/16"</b> 20.64 mm	SOCKET ACCESSORY ASSEMBLY	19291	19292	19293	19294	19295	19296
		SOCKET	19085	19086	19087	19088	19089	19090
		JIFFY KEY STALL	19025	19026	19027	19028	19029	19030
	<b>7/8"</b> 22.22 mm	SOCKET ACCESSORY ASSEMBLY	19297	19298	19299	19300	19301	19302
		SOCKET	19091	19092	19093	19094	19095	19096
		JIFFY KEY STALL	19025	19026	19027	19028	19029	19030
	<b>15/16"</b> 23.81 mm	SOCKET ACCESSORY ASSEMBLY	19303	19304	19305	19306	19307	19308
		SOCKET	19097	19098	19099	19100	19101	19102
		JIFFY KEY STALL	19025	19026	19027	19028	19029	19030