


FITS SERIES 4 FLUSH ATTACHMENTS




STALL FLUSH TYPE INSTALLATION

WRENCH KEY HEX CHART FOR
BREAK-AWAY FRANGIBLE COLLARS
FLUSH (NO SOCKET)

THE SOCKET HEX IS BUILT INTO THE GEAR
OF THE TOOL. NO SOCKET IS USED.



FLUSH JIFFY KEY



SERIES 4 FLUSH STALL TYPE						
PIN HEX	3/32" / 2.38 mm	1/8" / 3.17 mm	5/32" / 3.97 mm	3/16" / 4.76 mm	7/32" / 5.56 mm	1/4" / 6.35 mm
JIFFY KEY STALL	19322	19323	19324	19325	19326	19327