



# FITS SERIES 2 & 3 ATTACHMENTS



STALL TYPE INSTALLATION  
1.98mm JIFFY KEY



LENGTH OF SOCKET mm

JIFFY KEY HEX	SOCKET HEX	DESCRIPTION	6.35	12.7	25.4	38.1	50.8	63.5	76.2
1.98mm 5/64"	6mm	SOCKET ACCESSORY ASSEMBLY	21167	21168	21169	21170	21171	21172	21173
		SOCKET	21153	21154	21155	21156	21157	21158	21159
		JIFFY KEY 1.98mm STALL	18134	18135	18136	18137	18138	18139	18140
	7mm	SOCKET ACCESSORY ASSEMBLY	21174	21175	21176	21177	21178	21179	21180
		SOCKET	19616	19617	19618	19619	19620	19621	19622
		JIFFY KEY 1.98mm STALL	18134	18135	18136	18137	18138	18139	18140
	8mm	SOCKET ACCESSORY ASSEMBLY	21181	21182	21183	21184	21185	21186	21187
		SOCKET	19623	19624	19625	19626	19627	19628	19629
		JIFFY KEY 1.98mm STALL	18134	18135	18136	18137	18138	18139	18140
	9.5mm	SOCKET ACCESSORY ASSEMBLY	19735	19736	19737	19738	19739	19740	19741
		SOCKET	19630	19631	19632	19633	19634	19635	19636
		JIFFY KEY 1.98mm STALL	18134	18135	18136	18137	18138	18139	18140
	10mm	SOCKET ACCESSORY ASSEMBLY	19742	19743	19744	19745	19746	19747	19748
		SOCKET	19637	19638	19639	19640	19641	19642	19643
		JIFFY KEY 1.98mm STALL	18134	18135	18136	18137	18138	18139	18140
	11mm	SOCKET ACCESSORY ASSEMBLY		19750	19751	19752	19753	19754	19755
		SOCKET		19645	19646	19647	19648	19649	19650
		JIFFY KEY 1.98mm STALL		18135	18136	18137	18138	18139	18140

Denotes special use Socket Accessory Assembly for limited access areas.

For best results pins should not protrude through installed collars more than two threads.